


# PHILIPS

freeline

TGX-5000



## Operating Instruction

1. Set the sound box on the place that is symmetrical on both sides.
2. Connect the sound box according to the instruction, and turn on the power switch of the PC or external devices, and then press the power button of the sound box. The power indicator will be on.
3. When the volume button is used, you can regulate the desired volume by tuning it.
4. It can be used by hanging on the wall. (Just fold the bracket on the back and fix it on the wall.)

### ---Notices---

1. To avoid being hurt by the motor, user should make sure to install the sound box according to the instruction after purchasing it. When malfunctions occur, please refer to the warranty, and consult the agent or A/S center.
2. Please avoid high temperature, and do not expose it to the direct sun.
3. Please do not expose it to moist places or places of too much dust. Do not put the container with liquid onto the machine cover.
4. Please cut off the power if it is not in use for long.
5. Please make sure that no foreign substances enter into the machine.
6. Please do not clean the machine by using chemical solvent such as alcohol. When cleaning the machine, you may use a soft cloth wetted by mild cleanser.
7. Please do not jam the heat dispersing passage of the machine. When the machine is in use, it must be put in the circumstance of ventilation.
8. If no volume comes from the sound box, please make sure the power is connected.

